



## Installation Instructions – Suzuki V-Strom DL650

Thank you for purchasing a BUMOT luggage system for your motorcycle. BUMOT luggage, handcrafted in Bulgaria, is designed for the rider who demands the most durable and functional luggage for their adventure touring. We're confident you will enjoy your new luggage system for years to come.

Please read through these instructions completely before starting installation. Leave all hardware loose until all components are in place and initial assembly is completed. Once everything has been installed, tighten all bolts snugly. Do not apply liquid threadlock (Loctite or similar) to any bolt which has a self-locking nut.

### Installation Hardware Contents -

- M6 x 40mm Bolts – Qty 8
- M6 x 25mm Bolts – Qty 2
- M6 Washers – Qty 12
- M6 Self-Locking Nuts – Qty 2
- 23mm Spacers – Qty 4
- 20 mm Spacers – Qty 4
- 4mm Spacers – Qty 2

### Instructions –

1. Remove the four OEM bolts from the left side pannier rack mounting points.




2. Remove the two bolts that attach the passenger peg bracket and remove the assembly.



3. Attach the left side pannier rack to the frame with the included M6 x 40mm bolts, M6 washers, and spacers. Two 20mm spacers are used in the upper mounting points and two 23mm spacers are used in the lower mounting points.



4. Attach the forward mounting point of the rack on the left side as shown in photo. Use the 4mm spacer in the forward mounting hole between the passenger peg bracket and the frame, and reattach the passenger peg bracket to the bike using the OEM M8 bolts.



5. Repeat steps 1-4 to install the right side pannier rack.
6. Install the rear connecting bar with the supplied M6 x 25mm bolts, M6 washers, and M6 Self-Locking nuts as shown below.





7. Tighten all hardware and recheck after first 100 miles.

***Enjoy your new BUMOT luggage system!***

BUMOT Motorcycle Luggage

Ph:+359 887 649 709

[www.bumot.eu](http://www.bumot.eu)

[info@bumot.eu](mailto:info@bumot.eu)